



Shower Head Replacement

Replace a standard shower head.

Written By: Aaron Bartfeld



INTRODUCTION

Do you have a leaky shower head, or just want to replace it with the newest model? Use this guide for a stress-free installation



TOOLS:

- [Plumbers Tape](#) (1)
-

Step 1 — Shower Head



- Use your hand to loosen the old shower head from the pipe. This should be fairly easy, as most shower heads have a textured grip on the joint.
- ⚠ Make sure the water is turned off to the shower.

Step 2



- Once the shower head is loosened, remove it and set it aside.

Step 3



- Remove the old plumbing tape from the threads of the pipe, and throw it away.

Step 4



- Grab your roll of plumbing tape and wrap the tape approximately twice around the threads of the pipe.
- ⓘ Be sure to wrap the tape tightly to prevent leaks.

Step 5



- Begin installing the new shower head by threading it onto the pipe.

Step 6



- Use your hands to tighten the new shower head back onto the pipe, using a wrench if needed.
- ⓘ Make sure it is tightly connected!

Step 7



- Turn on the water and enjoy your new shower head!

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 06:11:36 AM.